ex 50 H3 dressed timber battens (spaced to suit ecoTUFF® sheets). Adhered to top of		
WarmSEAL insulation		4mm flameSEAL® cap sheet
		3mm flameSEAL® base sheet
H3 timber fillet 20mm min (to suit battens)		flameSEAL primer on substrate
		WarmSEAL polyiso insulation. Thickness determined by R-value required. Fixing by mechanical fixing
		or Lexphalt foam
		Lexshield peel + stick vapor barrier on substrate
		Plywood substrate
	<u> </u>	prime substrate with multigrip primer where required

WR fS D12 - Batten Join for Services Revision: 10 September 2019



Warm Roof Installation Details - flameSEAL

Batten Join

Date	Scale	Sheet	Rev.
November 2019	1:5	WR fS D12	