


Sealco EcoJACK

Recommended Spacings for Timber Joists or Bearers



EcoJACK Spacing Placement

175 x 50mm	=	1000mm	
150 x 50mm	=	800mm	
125 x 50mm	=	700mm	
100 x 50mm	=	600mm	
75 x 50mm	=	400mm	
50 x 50mm	=	300mm	
25 x 50mm	=	Not recommended	